

# Semi-Permanent Rugby Goals with Ground Sleeves

## Assembly Instructions

- Assemble by sliding the pieces together as shown.
  - Tighten thumb screws
  - The goal posts slide into the ground sleeves.
  - The ground sleeve is to be set in concrete.
- Call for FREE safety labels to affix to goals.

## Ground Sleeve

### Installation Instructions

- 1 Dig a hole 2 feet deep and 1.5 feet wide
- 2 Pack gravel into the base of the hole to stabilize the ground sleeve
- 3 Make sure the sleeves are level with the ground before permanently installing
- 4 Before cementing ground sleeves make sure the posts slide easily in and out of the sleeves
- 5 Cement posts into the ground with the caps on and allow to set for at least 24-48 hours or until ready
- 6 Crossbar should be 10' from the ground to the bar
- 7 Installation should be performed by a qualified contractor

